

## **eBike instructions**

This ebike is limited to 15mph and will deliver 250W of power average, peaking at more for hill climbing.

### **1. Approaching the bike.**



eBikes tend not to bite back, but you never know.

### **2. Checking brakes, adjusting seat height, and tucking in one's trouser leg.**

The brakes are connected to sensors which disconnect the power for extra safety.



### 3. Initialising the ebike system:


Turn on battery at the red rocker-switch ( see pictures ).




Turn on ebike display. If it doesn't turn of, try the battery rocker-switch in the other position.




Use the “Plus” button to set power level to ‘SPEED’ ( recommended minimum for hill-climbing ).




Press power button briefly, to activate the bike lights and / or illuminate the display.



Press “plus” again for TURBO setting, useful for steep hills.



Press “minus” to reduce the power level again to SPEED, or even TOUR or ECO.  
( Choose how much effort you would like to put in! )



Enjoy the ride.